

Troubleshooting Guide: LNG/NGL Cold Box — Freeze-up from Trace Water Carryover

Category: Cryogenic Processing / Flow Assurance **Unit:** Cryogenic Cold Box / Braze Aluminum Heat Exchanger (BAHX), NGL Recovery Section **Tools:** Cryogenic process simulation (low-temperature VLE) plus moisture/freeze-out risk review **Fluid Package:** Peng-Robinson (PR) with appropriate low-temperature binary interaction parameters, combined with a moisture/freeze-point check since PR alone does not predict solid ice/hydrate-like freeze-out of trace water **Symptom:** Increasing pressure drop across a cold box passage with a localized outlet temperature deviation, progressing toward partial flow restriction

1. Quick Reference

Item	Detail
Reported symptom	Rising differential pressure across a specific cold box passage; localized low outlet temperature deviation; developing partial flow restriction
Initially unclear	Whether this was a process condition change, an instrumentation issue, or physical blockage inside the BAHX
Actual root cause	A brief upstream molecular sieve breakthrough allowed trace water to slip past the dryer beds and freeze out inside the cryogenic exchanger passages, building an ice/hydrate-like blockage
Fix	Controlled warm-up/deicing of the cold box; confirmed upstream mol sieve moisture performance was corrected before resuming
Diagnostic signal	dP rise and localized temperature deviation consistent with a developing internal restriction, cross-referenced against upstream dehydration performance history
Prevention	Installed/verified online moisture analyzer downstream of the mol sieve beds, closing the detection gap that allowed the breakthrough to go unnoticed

2. Symptom

- **Rising differential pressure across a specific cold box passage.**
- **A localized low outlet temperature deviation** on that passage.
- Progressing over time toward a **partial flow restriction.**

3. Why This Wasn't Assumed to Be a Simple Process Upset

Rising dP and a localized temperature deviation in a cryogenic exchanger can result from several distinct causes: a genuine process rate/composition change, an instrumentation fault, or physical blockage inside the exchanger passages. Given the safety and reliability stakes of a cryogenic cold box, it was necessary to determine the actual mechanism — particularly whether **trace water** (which is catastrophic in cryogenic service, since it freezes solid) had made it past the upstream dehydration system.

4. Diagnostic Approach

Step 1 — Confirm the symptom pattern is consistent with an internal restriction

The combination of rising dP and a localized (not uniform) outlet temperature deviation pointed toward a developing **physical restriction inside a specific passage**, rather than a broad process condition change that would typically affect multiple passages more uniformly.

Step 2 — Cross-reference against upstream dehydration performance

Given that cold box freeze-up is a well-known consequence of trace water carryover, upstream **molecular sieve dehydration performance history** was reviewed for any recent anomaly.

This connects directly to the molecular sieve case (Case Study 10): a brief regeneration or cycle-timing issue on the mol sieve beds can allow a short window of water breakthrough that wouldn't necessarily register as an obvious upset at the time, but has serious downstream consequences once that moisture reaches cryogenic temperatures.

Finding: A **brief mol sieve breakthrough event** was identified in the historical record — a short-duration water slip that had not been caught by the process at the time.

Step 3 — Confirm the freeze-out mechanism

With bulk gas confirmed to be well below the freezing point of water in this section of the cold box, even a small amount of carried-over moisture would be expected to **freeze out and accumulate** on the exchanger's internal passages, consistent with the observed localized dP rise and temperature deviation.

Step 4 — Plan a controlled resolution

Given the safety-critical nature of cryogenic equipment, resolution required a **controlled warm-up/deicing procedure** rather than an abrupt intervention, to safely melt and clear the ice without risking mechanical damage to the aluminum exchanger.

Quantitative Basis

- Passage design dP at rated flow: 8 psi. Trended actual dP rose from **8.2 psi to 34 psi over 9 days**.
- Passage design outlet temperature: -152°F . Localized readings drifted to **-139°F — 13°F warmer**, while neighboring passages held steady at **-150°F to -154°F** .
- Retrospective review of the upstream mol sieve moisture analyzer found a **40-minute window where outlet dew point spiked to -35°F** against a -100°F spec, **5 days prior to the cold box symptom onset** — the undetected breakthrough event responsible for the freeze-out.

5. Root Cause

A brief upstream molecular sieve breakthrough allowed a small amount of water to slip into the cryogenic section, where it froze out inside the brazed aluminum exchanger passages, progressively restricting flow and producing the observed rising differential pressure and localized temperature deviation.

6. Corrective Action

1. Performed a **controlled warm-up/deicing** of the affected cold box passage.
2. **Verified upstream mol sieve moisture performance had been corrected** (see Case Study 10-style investigation) before resuming cryogenic operation.
3. Resumed normal operation once ice was cleared and upstream dehydration was confirmed sound.

7. Verification

- Passage differential pressure returned to **8.4 psi**, close to the 8 psi design value.
- Outlet temperature deviation resolved, reading **-151°F** — within 1°F of the -152°F design value.
- No recurrence over the following **30 days**, with continuous online moisture monitoring confirming outlet dew point held below -100°F throughout.

8. Prevention / Long-Term Fix

- **Installed/verified an online moisture analyzer downstream of the mol sieve beds**, closing the detection gap that had allowed the earlier breakthrough to go unnoticed until it manifested as a cold box symptom well downstream.

9. General Troubleshooting Checklist (Reusable)

- ☐ Confirm whether rising cold box dP and temperature deviation are localized to a specific passage (favors internal restriction) or broad/uniform (favors a process rate/composition change)
- ☐ Review upstream dehydration (mol sieve or equivalent) performance history for any recent breakthrough, regeneration anomaly, or cycle-timing issue
- ☐ Recognize that even a brief, short-duration moisture slip can cause a lasting cryogenic freeze-out problem — don't dismiss a past minor upstream anomaly as irrelevant just because it was brief
- ☐ Confirm bulk gas temperature in the affected section is below water's freeze point, supporting the freeze-out hypothesis
- ☐ Plan resolution as a **controlled** warm-up/deicing procedure appropriate to cryogenic/BAHX equipment — do not attempt abrupt thermal intervention
- ☐ Before resuming cryogenic operation, confirm upstream dehydration performance has been corrected and verified, not just that the ice has cleared
- ☐ Install or verify continuous moisture monitoring downstream of the dehydration system as an early-warning layer specifically protecting the cryogenic section

10. Key Takeaway

Cryogenic cold box problems are very often **upstream** problems that took time to manifest — a brief mol sieve breakthrough that seemed inconsequential at the time

can show up much later as a localized freeze-up deep inside a BAHX passage. When you see a developing internal restriction in cryogenic service, check upstream dehydration history before assuming a cold-box-specific mechanical cause, and treat online moisture monitoring downstream of the dryers as a safety-critical detection layer, not an optional nicety.

Related Concepts / Tags

cold-box BAHX freeze-up cryogenic-processing trace-water molecular-sieve-breakthrough
NGL-recovery moisture-analyzer flow-assurance Peng-Robinson

This guide is derived from a representative field troubleshooting scenario. Values and thresholds shown are illustrative and should be validated against your own unit's design basis before applying.